ACE AMPLIFICATION






OHCK STAAT HIDE

Important : always connect a speaker cabinet before powering on your ACE amplifier.

- Plug your amp into your speaker cabinet. Only use speaker cable to connect the amp and the cabinet. Use only ONE speaker output of the amp at a time. Check that the impedance of your speaker matches the selected speaker output of the amp.
- 2. Plug your power cable.
- Switch on the amp with the power switch. Allow approx 30s for the tubes to warm before you can get some sounds.

COMMECTIONS








Volume

ACE

Power



GAIN (Plexi) : adjusts the gain of the Plexi channel.
GAIN (Boost) : adjusts the gain of the Boost channel.
CHANNEL (switch) : selects channel. When using a footswitch, this switch is disabled.

Mid

Treble

Volume

BASS/MID/TREBLE : adjusts the amount of bass/mid/treble.

Notes : - Controls are shared between the two channels.

- Dialing TREBLE down can increase basses.
- When all controls are dialed all the way down, the amp doesn't produce any sound.

VOLUME (Plexi) : adjusts the volume of the Plexi channel.
VOLUME (Boost) : adjusts the volume of the Boost channel.
POWER : turns the amp ON of OFF. Switch should be illuminated when the amp is ON.

POWER MODE (on the back) : when LOW is selected, amp is operating in 2w mode.

